



sononic...inspiring simplicity




- Features:
- 15m transmission distance
 - touchpad mouse navigator
 - red laser pointer
 - page up/page down
 - rubberised coating finish
 - storable wireless receiver
 - 10 hour battery time
 - 2.4GHz digital connection
 - USB 2.0

WARNING: Laser radiation is harmful to the eyes. Do not point laser beam at anyone's eyes.
CAUTION: Use of controls or adjustments, or performance of procedures other than those specified herein may result in hazardous radiation exposure.

- ☐ left click
- ☐ right click
- ☐ laser pointer
- ⬆ page up
- ⬇ page down
- ⏪/ESC play/ESC
- ⏩ screen blank

touchpad mouse navigator



Touch the lens to use the mouse function

15.21 *Changes or modifications are not expressly approved by the manufacturer could void the user's authority to operate the equipment. Changes or modifications to the device may void FCC and CE compliance. In frequently used radio links should be tested regularly to protect against undetected interference or fault.*



cordless touch presenter

Installing the Battery


1. Push the battery cover down and away from the controller.
2. Align the AAA battery according to the (+) and (-) markings on the battery compartment.
3. Replace the battery cover sliding back until it clicks into place.



Caution:

- Only use the specified AAA battery.
- Insert battery according to (+) and (-) markings. Inserting the battery incorrectly may result in cracking or leakage, which may pose a risk of fire or lead to personal injury.
- Dispose of the battery in accordance with local laws and regulations. Please turn in your batteries at the responsible collecting point, or place of purchase.
- When the controller is not used for extended periods, please remove the battery.

Warning: Never dispose of batteries in fire, as they could explode.




Removing the Wireless USB Receiver

Locate the raised edge at the rear-end of the controller module. Push and slide out the wireless USB receiver.



Installing the Wireless USB Receiver

The wireless USB receiver is used like a regular USB flash drive. Plug the receiver directly into an available USB port of your notebook or computer. Windows 2000/XP/Vista/7/OS Mac 9.0 operating systems and later, the drive is automatically recognized and installed.



Note: If after installation, the USB receiver does not respond to the controller, please See "Frequency Search" for how to the frequency between controller and receiver.



Should the receiver not respond to the controller after installing the driver, reset the transmission and reception frequency between controller and wireless USB receiver using the following procedure.

1. Slide the power switch on, then plug the wireless USB receiver into an available USB port.
2. Press the **Connect Key** on the wireless USB receiver.
3. The **Status LED** starts flashing.
4. Press the connect key on the controller within 10 seconds while led is flashing.

Specification:

- Dimensions (L x W x H) : 12.4 x 4.65 x 3.3 cm
- Weight : 90g (incl. battery)
- Frequency : 2.4G
- USB interface : USB 2.0
- OS supported : Windows 2000, XP, Vista, 7, OS Mac 9.0 or later
- Laser wavelength : 630 ~ 680nm
- Output power : CL IIIa < 5mW , CL II < 1mW
- Power : AAA 1.5V battery x 2
- Battery burn time : 10 hours
- Finished : Rubber coating